

DESCRIPTION

XclusiveDecor™ Firenze Barbecue with side table

Ref.: 201701

Type: Natural limestone, fire cement
and red fire bricks

Dimensions (cm): H195 x W95 x D48

Weight (kg): 450



Included:
Burner BBQ
ref. BB5035



5 060473 850057 >

Included:

2 Pieces 95 x 40 x 5 (A)

4 Pieces 40 x 32.5 x 5 (B)

2 Piece 85 x 40 x 5 (C)

1 Piece 95 x 48 x 5 (D)

1 Piece 47 x 45 x 6 (E)
right side grill

1 Piece 54 x 45 x 5 (F)
red brick grill back

1 Piece 47 x 48 x 5 (G)
left side grill

1 Piece 53 x 35 x 5 (H)
red brick grill base

1 Piece chimney (I)


1 Piece flue (J)

1 Piece top (K)

1 Piece Burner BBQ with grill (L)

Dimensions (cm)

Silicone adhesive
required





SAFETY ADVICE



WE WOULD LIKE TO REMIND YOU THE INSTALLATION OF A BARBECUE REQUIRES A CERTAIN TECHICAL KNOWLEDGE OF THE ASSEMBLY METHODS. THIS IS WHY WE WOULD RECOMMEND THAT YOU CONTRACT SUITABLE INSTALLERS TO ASSEMBLE YOUR BARBECUE.

AT LEAST TWO PEOPLE ARE REQUIRED TO ASSEMBLE THE BARBECUE AS SOME OF THE COMPONENTS PARTS ARE HEAVY. KEEP CHILDREN AND ANIMALS AWAY FROM THE WORK AREA, TO PREVENT INJURIES.

MAKE SURE YOU HAVE ENOUGH SPACE TO LAYOUT THE PARTS BEFORE STARTING.

XCLUSIVEDECOR LTD IS NOT RESPONSIBLE FOR ANY ACCIDENT OR DAMAGED PARTS IT CAN HAPPEN DURING THE BARBECUE ASSEMBLY.

BEFORE ASSEMBLY:

- The parts are usually made of concrete, stone or brick and they are thus particularly sensitive to shock and vibrations during the assembly.
- Do not assemble your barbecue in fully-enclosed environments, must in addition be installed away from trees, plants and other flammable materials.
- The barbecue must be assembled on a rigid horizontal surface, it is not appropriate to set up directly on the ground, gravel, grass or similar. These surfaces may not be stable and will cause slopes on the barbecue thus causing cracks. Use silicone adhesive for fixing the parts together.
- The barbecue shall be installed in such a way that allows the specific swelling / contraction of this type of products, otherwise there maybe cracks. It should not be stuck to a wall, leaving clearance of around 5cm. The canopy shall be placed on the barbecue without using silicone adhesive.
- After the assembly is complete you should clean the dust of all concrete parts of your barbecue.

MAKING IT WORK:

- After assembly, the barbecue shall be dried thoroughly before using it.
- The first time you light the barbecue, this shall be done with charcoal, heating the embers then making them grow gradually for two of three hours, when first used, avoid very strong flames, as the concrete and brick need to progressively adapt to the high temperatures. For this purpose, the adaptation shall be carried out during the initial usages, burning firewood with a low heat potential. The resistance of your barbecue shall depend on the initial usages.
- Too much firewood causes a rapid initial combustion, which will produce a overheating of the barbecue.
- If the barbecue is mounted in an open area or if it is wet, perform a progressive low fire to avoid sudden changes in temperature, passing to a regular use when it is dry.
- After using the barbecue, you can remove the firewood charcoal which has been produced and which has not been consumed yet for subsequent usages. Remove the ashes, but do not wash the barbecue until it is totally cool.
- Under no circumstances may water be put on to cool or wash the barbecue. The barbecue may only be wet when it is totally cool sudden changes in temperature may cause cracks or the rupture of the concrete and the brick.
- Allow the silicone dry according to the silicone instructions before place your oven on the top of the stand.

FOR MORE INFORMATION, VIDEOS AND RECEIPS PLEASE VISIT XCLUSIVEDECOR.COM

Thank you for purchasing a product of XclusiveDecor™

XCLUSIVEDECOR.COM